

DRIPLoc ROOFTOP GREASE SYSTEMS





Hinges will come with rod in place

1. Start the bolts into the top two holes of both hinge leaves.
2. Slide the hinges to the fan base, lining up with curb.
3. Tighten the bolts until the hinge starts to spread 1/8". Do not over tighten.
4. Slide rod through the hinges.
5. Slide angle iron side onto rod and attach to side of curb.
6. Zip the self tapping screws into angle irons pre-drilled holes. (you will want a screw as close to the back edge as possible, you may have to make your own hole with a screw)
7. Repeat steps 4 and 5 on other side.
8. Screw the end of the safety chain to the very corner of the opposite side of fan base.
9. Attach the other end of chain to the curb, allowing appropriate slack.
10. Repeat step 8 and 9 to opposite side.
11. Using a hack saw cut access rod on both sides.
12. Put the caps on both ends of the rod.
13. For further info go to <http://www.youtube.com/watch?v=e7zwkSL3dtM>
14. Don't hesitate to call with questions